



ASSEMBLY INSTRUCTIONS.

- Fix the 2 legs to the vaulting horse before tightening the 2 external screws and after the internal screw for each leg.
- Insert the bases in the legs by pulling the knob to adjust the height and secure them with the handwheel.
- Fix the M10x40 screw into the hole at the center of the vaulting horse.
- Fix the winch to the vaulting horse using the M10x60 bolt and nut M10.
- Secure the anchor bolt to the floor and tighten the screw M10x40 with the ring.
- Attach the hook to the ring and lock the horse to the ground using the winch.

Vaulting horse



Art. 1155 -1156

Aggiornamento n° 1

Pagina: 1/1