



PRODUCT DESCRIPTION

Adjustable height support for dance bar 500 mm. circular steel base diam. 500 with holes for the floor fixing. Tot. weight 30 kg.

ASSEMBLY INSTRUCTION

Fix the main support to the base with screw M10x40

Fix dance bar (not included) using screw for wood 3.9x25

Adjust height with the hand wheel

We suggest floor fixing.

LIST OF COMPONENTS for 1 ART. 1595

n° 2 STRUCTURES

n° 2 CIRCULAR BASES

n° 2 SCREW m10X40

n° 2 HAND WHEELS m12X20

n° 8 SCREWS FOR WOOD 3.9X25

IMPORTANT

To anchor the structure at the floor use appropriate anchors.

WARNINGS

- Before starting the assembly or use the system, read carefully instructions and verify the presence of all the components. Control that all the fixings are well closed.
- Anchor with specific anchors.
- The constructor is not responsible for any eventually damages caused from a bad or not responsible use of it.

MAINTENANCE

- Once a year control the general condition of it.
- Once a year control that all the fixings are well closed;

In case of structural failures or deformations, breaks or anomalies in general, contact immediately the installer or the dealer.