

## USE OF THE WINCH TENSIONER



Insert the tape inside the winch.



To tension the net, pull the tape with the use of the special winch by moving the knob repeatedly first upwards and then downwards as in the image alongside.





To remove or decrease the tension of the belt, hold down the blade of the winch down and move the lever upwards as in the drawing. Then grab the ribbon and pull to remove it.